

How to Increase the Gas Flow in the Chambers

If access to the UX cavern **IS possible:**

- Option 1: Change the setting of the inlet Zimmerli P-regulator
- Option 2: open the needle valves of the flowcells

If access to the UX cavern **is NOT possible:**

- In the distribution rack, adjust, through the GCS Controls, the regulation valve by setting the outlet pressure to a lower value

