

Bin	H_T^{miss} [GeV]	H_T [GeV]	$N_{\text{b-jet}}$	$pp \rightarrow \tilde{g}\tilde{g}, \tilde{g} \rightarrow \text{bb}\tilde{\chi}_1^0$	$pp \rightarrow \tilde{g}\tilde{g}, \tilde{g} \rightarrow \text{tt}\tilde{\chi}_1^0$	$pp \rightarrow \tilde{g}\tilde{g}, \tilde{g} \rightarrow \text{qq}\tilde{\chi}_1^0$
				$m_{\tilde{g}} = 1500 \text{ GeV}$ $m_{\tilde{\chi}_1^0} = 100 \text{ GeV}$	$m_{\tilde{g}} = 1500 \text{ GeV}$ $m_{\tilde{\chi}_1^0} = 100 \text{ GeV}$	$m_{\tilde{g}} = 1000 \text{ GeV}$ $m_{\tilde{\chi}_1^0} = 800 \text{ GeV}$
25	200-500	500-800	0	0.00 ± 0.00	0.00 ± 0.00	10.75 ± 0.39
26	200-500	800-1200	0	0.00 ± 0.00	0.01 ± 0.00	8.05 ± 0.34
27	200-500	1200+	0	0.15 ± 0.01	0.06 ± 0.00	1.79 ± 0.16
28	500-750	500-1200	0	0.00 ± 0.00	0.01 ± 0.00	2.77 ± 0.20
29	500-750	1200+	0	0.13 ± 0.01	0.05 ± 0.00	1.40 ± 0.14
30	750+	800+	0	0.13 ± 0.01	0.05 ± 0.00	1.45 ± 0.15
31	200-500	500-800	1	0.00 ± 0.00	0.01 ± 0.00	2.86 ± 0.12
32	200-500	800-1200	1	0.02 ± 0.00	0.03 ± 0.00	2.23 ± 0.11
33	200-500	1200+	1	0.49 ± 0.02	0.19 ± 0.01	0.53 ± 0.05
34	500-750	500-1200	1	0.02 ± 0.00	0.03 ± 0.00	0.85 ± 0.07
35	500-750	1200+	1	0.44 ± 0.02	0.16 ± 0.01	0.43 ± 0.05
36	750+	800+	1	0.44 ± 0.01	0.17 ± 0.01	0.34 ± 0.04
37	200-500	500-800	2	0.00 ± 0.00	0.01 ± 0.00	0.47 ± 0.04
38	200-500	800-1200	2	0.04 ± 0.00	0.05 ± 0.00	0.37 ± 0.03
39	200-500	1200+	2	0.61 ± 0.02	0.24 ± 0.01	0.12 ± 0.02
40	500-750	500-1200	2	0.03 ± 0.00	0.05 ± 0.00	0.15 ± 0.02
41	500-750	1200+	2	0.56 ± 0.02	0.20 ± 0.01	0.08 ± 0.02
42	750+	800+	2	0.56 ± 0.02	0.21 ± 0.01	0.05 ± 0.01
43	200-500	500-800	3+	0.00 ± 0.00	0.01 ± 0.00	0.06 ± 0.01
44	200-500	800-1200	3+	0.04 ± 0.01	0.04 ± 0.00	0.04 ± 0.01
45	200-500	1200+	3+	0.49 ± 0.02	0.19 ± 0.01	0.02 ± 0.01
46	500-750	500-1200	3+	0.03 ± 0.00	0.04 ± 0.00	0.01 ± 0.00
47	500-750	1200+	3+	0.44 ± 0.02	0.15 ± 0.01	0.02 ± 0.01
48	750+	800+	3+	0.43 ± 0.02	0.16 ± 0.01	0.01 ± 0.00